



## CCD-2DC INSTALL GUIDE


## **DIMENSIONAL RENDERINGS**














Overall Product Dimensions				
Model No.	Height	Width	Depth	
CCD-2DC	24 1/8"	45 <sup>1</sup> /4"	18 <sup>3</sup> /8"	

Cutout Dimensions for Island				
Model No.	Height	Width	Depth	
CCD-2DC	20 <sup>1</sup> /4"	43 3/8"	17 <sup>1</sup> /8"	

## Install Notes:

- ✓ 2 anchor points are located on each side of the doors interior frame (top, bottom, left and right)
- ✓ Due to wide variance of possible building materials, anchors are not included
- √ When inserting your anchors be sure to use a framing square to ensure the door is not pulled out of square
- ✓ Additional framing and/or support underneath the rear (hanging portion) of the cabinet is recommended
- These specs are accurate but we always suggest having the product physically on site to ensure full understanding of how this product will coordinate with your build

